

Egalfloor Fini 5 mm: 22 x 80 x 57 cm (10,03 m²)

Art. nr - 62072

estillon
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



Installation instruction

- Softboard is a natural product; you should let it acclimate for 24 hours in the sealed packaging where it will be laid before installation.
- The ideal humidity for installing softboard is between 50-70% and the processing temperature is 15-20 degrees Celsius.
- Ensure that the surface is completely grit-free, dust-free, and permanently dry before installation.
- Start by applying a vapor barrier film of 150-200 microns.
- Lay softboard in a staggered pattern. Leave ± 2 mm space between boards. Leave ± 8 -10mm space along walls, heating pipes, and other fixed objects to account for subfloor movement.
- Due to the limited point load resistance of softboard, a softboard underlay is less suitable for spaces with heavy furniture or chairs/furniture with thin legs. In this case, choose an

Egalfloor Fini 5 mm: 22 x 80 x 57 cm (10,03 m²)

Art. nr - 62072



underlay with higher compression strength such as Floorfixx fini.

Top side

N/A.

Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.