

# Carpet Cushion 11 mm: 5,5 x 1,37 m (7,5 m<sup>2</sup>)

Art. nr - 68131

**estillon**  
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



## Installation instruction

- Let the underlay, just like the carpet to be installed, acclimatize in the closed packaging for at least 24 hours in the space where it will be installed.
- The ideal humidity for carpet installation is between 50–70% and the processing temperature is 15–20 degrees Celsius.
- Work clean and ensure that the substrate is completely grit-free, dust-free, and dry before installation.
- For cutting the underlay, we recommend a standard trapezium (snap-off) blade or carpet knife.
- An underlay cannot prevent the natural movement of a carpet.
- Always follow the installation advice of the carpet manufacturer and adhesive supplier to prevent problems during installation.

# Carpet Cushion 11 mm: 5,5 x 1,37 m (7,5 m<sup>2</sup>)

Art. nr - 68131



## Top side

Install with the crepe side facing upwards.

## Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.