

Dampproof antislip protection felt 25 x 2 m

Art. nr - R903 A2

estillon
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



Installation instruction

- Allow the underlay, like the carpet to be installed, to acclimatize in the sealed packaging for at least 24 hours in the room where it will be installed.
- The ideal humidity for a carpet installation is between 50–70% and the working temperature is 15–20 degrees Celsius.
- Work cleanly and ensure that the substrate is completely free of debris, dust, and dry before installation.
- For cutting the underlay, we recommend a standard trapezoid (snap-off) blade.

Top side

N/A.

Dampproof antislip protection felt 25 x 2 m

Art. nr - R903 A2



Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.