

# Woodstep 3 mm: 11 x 1 m (11 m<sup>2</sup>)

Art. nr - 68592

**estillon**  
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



## Installatie instructie

- Let the underfloor, like the top floor to be installed, acclimatize in the closed packaging for at least 24 hours in the room where it will be installed.
- The ideal humidity for installation is between 50–70% and the working temperature is 15–20 degrees Celsius.
- Work cleanly and make sure the substrate is completely free of debris, dust-free, and dry before installation.
- For cutting the underfloor, we recommend a standard trapezium snap-off knife or a carpet knife.
- An underfloor cannot prevent the natural movement of a floor.
- We advise always following the installation instructions of the parquet or laminate supplier.