

# Floorfixx fini 8 mm: 85 x 59 cm (5.015 m<sup>2</sup>)

Art. nr - 62074

**estillon**  
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



## Installation instruction

- Always allow Floorfixx fini to acclimatize for 48 hours in the closed packaging horizontally in the area where it will be installed.
- The humidity should be between 50-70% and the ideal processing temperature is 15-20 degrees Celsius.
- Ensure that the subfloor is completely dust-free and dry before installation.
- Always apply a vapor barrier PE foil with a minimum thickness of 150 µm in advance. Let the foil rise about 5 cm against the baseboard/wall. The strips of the foil should overlap each other by approximately 20 cm, or the seams must be taped.
- For the laying instructions, please refer to the product page of Floorfixx fini.
- Floorfixx fini is laid floating in a staggered pattern with the MDF side facing up.

# Floorfixx fini 8 mm: 85 x 59 cm (5.015 m<sup>2</sup>)

Art. nr - 62074

- Slide the panels firmly against each other and tap the tongue-and-groove connection firmly with a rubber mallet.
- When installing on plank subfloors, Floorfixx fini should be installed diagonally in the room.
- Leave a 10 mm gap along walls, heating pipes, and other fixed objects so that the floor has enough space to expand.
- If the vinyl needs to be fixed, we recommend using double-sided tape. Where full bonding is desired, we recommend Floorfixx smart, as Floorfixx fini is not suitable for gluing.
- For dimensions greater than 10 meters in length and/or width, an expansion joint should be made every 10 meters in both the Floorfixx and the floor covering.
- For optimal results, we recommend lightly sanding the seams by hand (grain size 80) and checking for height differences.
- Install the floor covering within 24 hours after installation of Floorfixx fini.

**Important:** Floorfixx fini is not suitable for bonding, as the MDF surface and edges can swell due to moisture exposure. Floorfixx fini is not applicable in damp areas. Work cleanly and ensure the tongue-and-groove is free of dust and dirt.

## Top side

MDF

## Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.