

# Starbase Green 6 mm: 10 x 1.50 m (15 m<sup>2</sup>)

Art. nr - 718211

**estillon**  
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



## Installation instruction

- Allow the underlayment, like the carpet to be installed, to acclimate for at least 24 hours in the closed packaging in the room where it will be installed.
- The ideal humidity for carpet installation is between 50–70% and the processing temperature is 15–20 degrees Celsius.
- Work cleanly and ensure that the substrate is completely grit-free, dust-free, and dry before installation.
- For cutting the underlayment, we recommend a standard trapezoid utility knife or a carpet knife.
- An underlayment cannot prevent the natural movement of a carpet; therefore, we advise always double-bonding carpets that are prone to shrinkage.

# Starbase Green 6 mm: 10 x 1.50 m (15 m<sup>2</sup>)

Art. nr - 718211



- Always follow the installation advice of the carpet manufacturer and the glue supplier to avoid problems during installation.

## Top side

Install with the crepe side facing upwards for double-sided bonding and the tension-fit method.

## Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.