

Egalfloor Classic 7 mm: 85 x 59 cm (7,52 m2)

Art. nr - 620612

estillon
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



Installation instruction

- You should allow the product to acclimate in the sealed packaging for at least 24 hours in the room where it will be installed before installation.
- The ideal humidity level for the installation of softboard is between 50–70%, and the processing temperature is 15–20 degrees Celsius.
- Ensure the subfloor is completely grit-free, dust-free, and dry before installation.
- Start by laying a vapor barrier film of 150–200 microns. The film layers should overlap by about 20 cm and the seams should be taped with suitable tape.
- Lay softboard in a half-brick pattern. Leave ± 2 mm space between the boards. Keep a space of ± 8 –10 mm along walls, heating pipes, and other fixed objects due to the movement of the subfloor.
- When gluing, use a liquid moisture barrier and always double-sided gluing.

Egalfloor Classic 7 mm: 85 x 59 cm (7,52 m2)

Art. nr - 620612

- Due to the limited point load resistance of softboard, a softboard underlay is less suitable for rooms with heavy furniture or chairs/furniture with thin legs. In this case, choose an underlay with higher compressive strength, such as Elegance Black FR.
- Carpets suitable are those that do not exhibit excessive movement due to fluctuations in humidity and temperature.
- In general, coconut, sisal, seagrass, and closely-cropped bouclé carpet are not suitable.
- Always consult your carpet supplier and also contact your adhesive supplier.

Top side

N/A.

Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.