

# Black Magic 6 mm: 11 x 1.37 m (15.07 m<sup>2</sup>)

Art. nr - 681181

**estillon**  
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



## Installation instruction

- Allow the underlay to acclimatize in the packaging, just like the carpet to be installed, for at least 24 hours in the room where it will be installed.
- The ideal humidity for carpet installation is between 50–70%, and the working temperature is 15–20 degrees Celsius.
- Work cleanly and ensure that the subfloor is completely free of debris, dust, and dry before installation.
- For cutting the underlay, we recommend a standard trapezoidal (snap-off) blade or an upholsterer's knife.
- An underlay cannot prevent the natural behavior of a carpet; therefore, we advise always double-gluing carpets that are sensitive to shrinking.

# Black Magic 6 mm: 11 x 1.37 m (15.07 m<sup>2</sup>)

Art. nr - 681181

- Always follow the installation advice of the carpet manufacturer and adhesive supplier to prevent issues during installation.

## Top side

681171 Black Magic 4 mm: 11 x 1.37 m (15.07 m<sup>2</sup>): Install with the black side facing downwards for double-sided bonding and the tension-fit method.

681181 Black Magic 6 mm: 11 x 1.37 m (15.07 m<sup>2</sup>): Install with the black side facing downwards for double-sided bonding and the tension-fit method.

681201 Black Pearl 5 mm: 7.30 x 1.37 m (10 m<sup>2</sup>): Install with the crepe side facing upwards for double-sided bonding and the tension-fit method.

## Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.