

# Egalbase 7 mm: 10 x 1,50 m (15m<sup>2</sup>)

Art. nr - 716711

**estillon**  
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



## Installation instruction

- Allow the underlay, like the carpet to be installed, to acclimatize in the closed packaging for at least 24 hours in the room where it will be installed.
- The ideal humidity for a carpet installation is between 50–70% and the installation temperature is 15–20 degrees Celsius.
- Work clean and ensure the substrate is completely debris-free, dust-free, and dry before installation.
- For cutting the underlay, we recommend using a trapezoid knife.
- To fix the self-adhesive backing to the substrate, use a roller with a maximum weight of 30 kg.
- An underlay cannot prevent the natural movement of a carpet; therefore, we recommend always double-gluing shrink-sensitive carpets.

# Egalbase 7 mm: 10 x 1,50 m (15m<sup>2</sup>)

Art. nr - 716711

- Always follow the installation advice from the carpet manufacturer and adhesive supplier to prevent problems during the installation.

**Important:** Roll out the Egalbase 7 mm underlay and lay it out generously with the adhesive layer down and the seams against each other. Fit the head and side edges. Ensure that the underlay is not under tension and then rub it in well. When stretching the carpet, it is recommended to tape the seams with tape. To accommodate potential shrinkage, we advise gluing the underlay along the edges approximately 10–15 cm (about one adhesive comb width) extra with universal carpet adhesive. For shrink-sensitive carpets, full double-sided gluing is required.

## Top side

Install with the crepe side facing upwards.

## Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.