
Duralay Silentfl. Plus2 3 mm: 1.37 x 7.29 m (10 m²)

Art. nr - 114100123

Scan this QR code to view this product on our website.




Installation instruction

Floating installation

Underlays for parquet and laminate can absorb minor irregularities in the subfloor. This creates a stable base for the floor. Depending on the product, the underlay can also contribute to impact sound reduction, walking comfort, thermal insulation and protection against moisture. Not every underlay has an integrated damp-proof membrane. Check in advance whether a separate damp-proof membrane is required. This depends on the underlay, the type of subfloor and the floor manufacturer's specifications.

Duralay Silentfl. Plus2 3 mm: 1.37 x 7.29 m (10 m²)

Art. nr - 114100123



1. Make sure the subfloor is level, sound, dry and free from dust, grease and other contaminants. Fix loose floor sections and remove or level off any protruding parts.
2. If required, first fit a suitable damp-proof membrane. Follow the product-specific installation instructions.
3. Lay the underlay in the prescribed laying direction and with the correct side facing up or down. Butt the rolls tightly together and avoid gaps and overlaps.
4. Join or tape the seams in line with the installation instructions for the underlay concerned. For a moisture-resistant floor build-up, use a suitable moisture-resistant tape.
5. Install the parquet or laminate floating on the underlay. Maintain the prescribed expansion gap along walls and other fixed building elements.
6. Finish the floor with skirting boards or trims. Always follow the installation instructions of the underlay and floor manufacturer.

General installation instructions

Duralay Silentfl. Plus2 3 mm: 1.37 x 7.29 m (10 m²)

Art. nr - 114100123

- Check that the underlay is suitable for the subfloor, the floor covering and the application
- Allow the underlay and floor covering to acclimatise before installation, in line with the product specifications
- Ensure suitable temperature and humidity conditions
- Check that the subfloor is level, sound, dry and clean
- Remove dust, grease, adhesive residue and other contaminants
- Repair loose sections, damage and major unevenness
- If in doubt, measure the moisture content of the subfloor
- If required, apply a primer, levelling compound or separate damp-proof membrane
- Lay the underlay with the prescribed side facing and in the correct laying direction
- Butt the seams tightly and avoid gaps, overlaps and differences in height
- Maintain the prescribed expansion gap along walls and fixed building elements
- Use only suitable adhesives, tapes and installation products
- With underfloor heating, follow the specifications of the underlay and floor manufacturer
- Always consult the product-specific installation instruction

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims resulting from incorrect installation. If in doubt, always consult your supplier.