

Starbase Green FR 10 mm: 10 x 1,50 m (15 m²)

Art. nr - 718231

estillon
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



Installation instruction

- Allow the underlayment, like the carpet to be installed, to acclimate for at least 24 hours in the closed packaging in the room where it will be installed.
- The ideal humidity for carpet installation is between 50–70% and the processing temperature is 15–20 degrees Celsius.
- Work cleanly and ensure that the substrate is completely grit-free, dust-free, and dry before installation.
- For cutting the underlayment, we recommend a standard trapezoid utility knife or a carpet knife.
- Install the underlay without tension and do not stretch the material during installation.
- Press the underlay evenly into the adhesive bed. Avoid pulling or stretching while pressing it down, as this may cause dimensional changes or shrinkage after installation.

Starbase Green FR 10 mm: 10 x 1,50 m (15 m²)

Art. nr - 718231



- An underlayment cannot prevent the natural movement of a carpet; therefore, we advise always double-bonding carpets that are prone to shrinkage.
- Installation: perpendicular to the laying direction of the carpet. Avoid aligning the seams of the underlay with the seams of the carpet.
- Always follow the installation advice of the carpet manufacturer and the glue supplier to avoid problems during installation.

Top side

Install with the crepe side facing upwards for double-sided bonding and the tension-fit method.

Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.