

Floorfixx comfort 10 mm: 120 x 60 cm (2,88 m²)

Art. nr - 62210

estillon
WE WILL IMPROVE YOUR FLOOR

Scan this QR code to view this product on our website.



Installation instruction

- Acclimatise Floorfixx horizontally for at least 48 hours in its closed packaging in stacks of no more than 5 units in the room where it will be installed.
- The humidity should be between 50-70% and the ideal processing temperature is 15-20 degrees Celsius.
- Ensure the subfloor is completely dust-free and dry before installation.
- Always apply a damp-proof PE foil with a minimum thickness of 150 µm first.
- Allow the foil to stand approximately 5 cm against the skirting board/wall. The strips of foil should overlap by about 20 cm or the seams must be taped.
- Check the installation instructions on the insert sheet.
- Floorfixx consists of two parts: a) An MDF base board with insulating underlayer and a top layer featuring an interactive adhesive, covered with protective film. b) An MDF top board

Floorfixx comfort 10 mm: 120 x 60 cm (2,88 m²)

Art. nr - 62210

estillon
WE WILL IMPROVE YOUR FLOOR

featuring an interactive adhesive. The system is created by placing the MDF top board onto the base board after removing the protective film and pressing/rolling it firmly.

- For laying instructions, please refer to the Floorfixx Comfort product page.
- Maintain a 10 mm gap along walls, heating pipes, and other fixed objects to allow the floor room to expand.
- Floorfixx can easily be cut to size with a concave knife. Tip: Use other boards as a square during cutting to ensure a clean edge.
- After installation, roll the entire floor with a heavy 50 kg roller in both the length and width of the floor.
- Install the floor covering within 24 hours of installing Floorfixx.
- For gluing the floor covering, we recommend using a suitable adhesive applied with a microfiber roller or a fine-toothed A1/A2 notched trowel. To avoid moisture issues, strictly follow the adhesive manufacturer's recommended open time.
- For dimensions exceeding 10 meters in length and/or width, an expansion joint must be created every 10 meters in both Floorfixx and the floor covering.
- For optimal results, we recommend lightly sanding the seams by hand (80 grit) and checking for height differences.

Important: Do not install floor coverings < 2 mm to prevent telegraphing issues! Floorfixx is not suitable for damp rooms! Floorfixx cannot prevent indentations in the floor covering; use felt pads to limit these. Floorfixx levels a maximum height of 3 mm over 1 linear meter. Work cleanly, do not walk on the adhesive layer, and ensure it remains free of dust and dirt.

Top side

MDF

Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.