Black Square 5 mm

Art. nr - 62280

Scan this QR code to view this product on our website.



Installation instruction

- Allow Black Square 5 mm to acclimatize for at least 24 hours in a sealed package in the room where it will be laid.
- The ideal humidity for the installation of a parquet/laminate floor is between 50–70%, and the processing temperature is 15–20 degrees Celsius.
- The subfloor must be clean and permanently dry.
- Always first install a moisture barrier/PE foil on the subfloor. Overlap the joints by at least 20 cm and seal them with aluminum tape.
- The underlay panels should always be laid loosely in a staggered pattern, with the long seams in the direction of light incidence.
- Keep a space of 10 mm clear along the wall and any obstacles.

- Always install Black Square 5 mm crosswise under the laminate or parquet. The long seams of the underlay are perpendicular to the long seams of the laminate or parquet. On a wooden subfloor, always install Black Square 5 mm at a 45-degree angle.
- We recommend always following the installation advice of the floor supplier.

Top side

N/A.

Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.