

Scan this QR code to view this product on our website.



Installation instruction

- Work cleanly and ensure that the surface for installation is completely dry, grease-, grit-, and dust-free.
- Do not install on a recently coated floor (resin floor). To prevent chemical reactions between Luxerton and the coating, we recommend a waiting time of at least three months.
- For cutting to size, we recommend using textile scissors or a sturdy kitchen scissors.
- If the floor has been treated with lacquer, wax, or oil, it is essential that no chemical residues from this treatment remain on the floor. The floor must be completely cured before the carpet underlay is installed.
- The carpet underlay should not serve as a vapour barrier.

Maintenance advice:

- Use only professional cleaning agents suitable for your (hard) floor. Do not use regular household products; these can damage the maintenance or lacquer layer and cause discoloration. There's also a chance that a new layer of polish or maintenance product may not adhere well.
- The floor must be able to ventilate sufficiently; lay the carpet open several times a year to air. In case of condensation problems, the floor may discolour. Moisture from the substrate can rise and cause unsightly spots if insufficiently ventilated.
- The carpet underlay is sensitive when exposed to direct sunlight for extended periods; this can lead to drying out.
- The carpet underlay is not machine washable; hand wash only up to a maximum of 30 °C.
- The carpet underlay must not be tumble dried.
- The carpet underlay must not be ironed.

Top side

N/A (except for item 67860/67861/67862 Luxerton Superior. – With the printed side facing upwards).

Disclaimer

If the installation instructions are not followed, Estillon cannot be held liable for damage and/or claims arising from incorrect installation. If in doubt, always consult your supplier.