

Toepassing

Voor particuliere en projectmatige toepassingen. Elegance® kan zowel bij een gespannen als een dubbelzijdig verlijmde tapijtinstallatie worden toegepast.

Tapijt

Geschikt zijn tapijten die geen overmatige werking ten gevolge van schommelingen van vochtigheid en temperatuur e.d. vertonen. In het algemeen kan gesteld worden dat kokos, sisal en zee gras niet geschikt zijn voor verlijming op Elegance® ondertapijt. Informeer altijd bij uw tapijtleverancier.

Temperatuur/vochtigheid

I.v.m. droging van lijm en werking van tapijt is de ideale temperatuur ca. 18-20° C (15° C vloertemperatuur) en de ideale luchtvochtigheid 50-60%.

Ondergrond

Moet schoon, vet- en stofvrij zijn om een goede hechting te krijgen. Parket en tegelvloeren eerst ontvetten. Afzandende betonvloeren, niet gelakte houten vloeren en kurken vloeren voorstrijken met UZIN PE 360. Anhydriet eerst voorstrijken met UZIN PE 240 Uniprimer of UZIN PE 360.

Stofzuigen

Zeer grondig stofzuigen: op stoffige ondergrond is geen hechting mogelijk!

Uitleggen

Elegance® uitrollen en met de crêpe zijde naar boven ruim uitleggen met de naden tegen elkaar. De kopse- en zijkanten pas maken. Let op dat de Elegance® niet onder spanning staat! Bij dubbele verlijming de banen Elegance® half terugslaan en (fixeer)lijm op de vloer aanbrengen.

Vervolgens de banen weer sluiten en het Elegance® ondertapijt zorgvuldig aanwrijven of rollen. Bij spannen van tapijt verdient het aanbeveling om de naden met tape af te plakken en de randen van het ondertapijt op de grond te fixeren om verschuiven te voorkomen.

Legrichting

Haaks op de legrichting van het tapijt. Voorkom dat de naden van Elegance® en van het tapijt samenvallen.

Tapijt leggen

Het te leggen tapijt in de ruimte uitleggen en naden pas snijden. Bij een gespannen installatie de naden lassen met geschikt Heatbond nadenlasband, alvorens het tapijt wordt gespannen. Bij dubbele verlijming de tapijtbanen voor de helft terugslaan en begin met het aanbrengen van de lijm op het ondertapijt.

Verlijmen

Elegance® voorzien van Egalbond of Easybond, UZIN KE 2570, UZIN KE 2005 beveelt deze lijmen aan, omdat deze uitvoerig zijn getest en de goede werking hebben aangetoond.

Gebruik voor het aanbrengen van de lijm een kitstrijker met de vertanding A2. Controleer aan de rugzijde van de vloerbedekking of voldoende lijm is aangebracht: de rug dient geheel voorzien te zijn van lijm. Zo nodig andere vertanding gebruiken. Afhankelijk van de temperatuur en luchtvochtigheid 10 tot 15 minuten wachten en het tapijt inleggen.

Aanwrijven

Elegance® zorgvuldig aanwrijven, bij voorkeur met een lichte tapijtglijder of roller (30 kg). Het aanwrijven is erg belangrijk om Elegance® goed te fixeren aan de ondergrond.

Belasten

Zo min mogelijk op het vers verlijmd tapijt lopen na het aanwrijven. Het is aan te bevelen de ruimte de eerste uren niet te belasten. Na 24 uur heeft Elegance® zijn optimale indrukherstellend vermogen bereikt.

Belangrijk

Volg altijd de aanwijzingen van uw tapijt- en lijmfabrikant op!

Elegance® is een gepatenteerde merknaam van Estillon BV

Application

For domestic and commercial applications. Elegance® can be used for stretched as well as fully glued (double-stick) carpet installations.

Carpet

Suitable for all kinds of carpets that are not over-sensitive to humidity and changes in temperature. In general, cocos and sisal carpets are not suitable for gluing down on Elegance® underpadding. Please consult the supplier of your carpet.

Temperature/humidity

In view of the drying time of the adhesive and shrinking of the carpet, the ideal temperature during installation is about 18-20°C. (15°C. on the floor) and 50-60% humidity.

Subfloor

Subfloor must be clean, dry and free of dust for a proper fixing. Parquet and tiles have to be cleaned to be free of wax and grease. Absorbing subfloors and anhydrite floors need special treatment before installation and have to be primed.

Vacuum cleaning

Clean very carefully, dusty floors can effect the installation.

Installation of underlay

Roll out the Elegance® with the crêpe paper side up. Be sure that the Elegance® is not stretched and leave no gaps, nor overlaps where width are butt-joined. In case of double stick installation, fold back half of the underpadding and apply the adhesive on the floor. Put the Elegance® back into the adhesive and rub or roll the underpadding carefully. In case of a stretched installation it is advised to tape the seams of the Elegance® and fix the perimeter with adhesive in order to prevent sliding of the Elegance® underpadding.

Direction of installation of underlay

Always install the underlay in a 90° angle underneath the length of the carpet in order to avoid matching of seams in underlay and carpet.

Installation of carpet

Lay the carpet in the room and cut to shape slightly larger than the subfloor area and prepare the seams. In case of a stretched installation prepare the seams with Heatbond carpet seaming tape before stretching. In case of a double stick installation, fold back half of the carpet and start applying the adhesive on the underpadding.

Glue down the carpet

Apply the recommended glue on the paper top of the Elegance® underpadding. Use an A2 notched trowel and check the backing of the carpet if enough adhesive is transferred. The backing should be covered entirely with adhesive. Depending of temperature and humidity, respect a dryingtime of approx. 15 min. (follow instructions of adhesive manufacturer). Lay the carpet into the adhesive.

Rolling/Rubbing

Rub the carpet plus Elegance® thoroughly, preferably with a light roller (30 kg) or a Carpet Glider, in order to get a proper bonding to the subfloor.

Accessibility

Avoid any (foot) traffic on the installed glued down carpet after rolling. Do not enter the room during the first few hours. After 24 hours Elegance® has reached its optimum adhesion and recovery capacity.

Important note

Always follow the instructions of the carpet- and/or adhesive manufacturer.

Elegance® is a registrated brandname of Estillon BV – The Netherlands