

- Let the carpet as well as the underpadding acclimatize for 24 hours in the original packing in the room to be installed.
- The best temperature for installation is 5-20°C. and a humidity of 50-70%.
- Make sure that the underfloor is absolutely dry and free of grit and dust.
- To cut the underpadding we recommend to use a trapezium blade.
- Underpadding can not prevent the natural shrinkage of carpet. Always follow the installation instructions of the carpet Manufacturer.

Important

In case the installation has not been done in accordance with the installation instructions, Estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.