

XPS Laminate 2,2 mm (68836)

XPS Laminate 2.2 mm is a high density XPS foam with a moisture barrier. XPS Laminate 2.2 mm has a high compressive strength and creates a fully flat and smooth basis for your laminate floors. XPS Laminate 2.2 mm is suitable for laminate floorings for domestic and commercial use.

- High Compressions strength (CS > 90 kPa/m²)
- High level of load resistance
- Moisture barrier
- Suitable in combination with floor heating

Installation method : Floating installation. Instal with the moisture barrier up.

Direction of installation method Always install the underlay in a 90° angle underneath the length of the floorcovering in order to avoid matching of seams in underlay and floorcovering.

General building inspection license: NA

Thickness: 2.2 mm / ± 0,22 mm - maximum tolerance 10%

Dimensions: 5,1 m x 1,18 m = ± 6,018 m²

Weight: 70 gr/m² / ± 7 gr/m² - maximum tolerance 10%

Density: 32 kg/m³ / ± 3 kg - maximum tolerance 10%

Material:
Top Layer : Moisture barrier
Bottom Layer : High density XPS foam

Packing: Material : Pe foil, with insert sheet .

XPS Laminate 2,2mm (68836)

Technical information:

<i>Punctual conformity</i>	: > 0.5mm
<i>Compressive strenght</i> (test method: EN 826 + Annex a)	: Class CS1 - CS > 90kPa/m2
<i>SD / vapor resistance</i>	: > 75 mikron
<i>Caster chair test</i> (Test method: EN 985)	: Passed
<i>Impact sound reduction</i> (Test method: NA)	: $\Delta L_w = 19\text{dB}$
<i>Thermal resistance</i> (Test method: NA)	: 0,8 togs - 0,08m ² K/W
<i>Fire retardency</i> (Test methode: EN ISO 9239-1)	: Efl
<i>ASTM radial panel test</i> (Test methode: ASTM E 648-06)	: NA
<i>Russian requirements on fire safety</i> (Test methode: FZ-123)	: NA

Installation instructions:

- Let the floorcovering as well as the underpadding acclimatise for 24 hours in the original packing in the room to be installed.
- The best temperature for installation is 5-20° C. and a humidity of 50-70%.
- make sure that the underfloor is absolutely dry and free of grit and dust.
- To cut the underpadding we recommend to use a trapezium blade.
- Underpadding can not prevent the natural shrinkage of Floorcovering. For that reason we strongly advise to leave a gap a 8-10mm allong all walls. Always follow the installation instructions of the floorcovering manufacturer.

Important:

In case the installation has not been done in accordance with the installation instructions, estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.



estillon
estillon
estillon
estillon

