Soundstop 2mm



Soundstop 2mm is a PE foam. Soundstop 2mm has a high compressive strength and creates a fully flat and smooth basis for your wooden floors. Soundstop 2mm is suitable for parquet/laminate floorings for domestic use.

- Excellent acoustical improvement
- Stable and easy to install
- Good sound reduction
- Suitable in combination with floor heating

Installation method: Floating installation.

Direction of installation method Always install the underlay in a 90° angle underneath the length of the

floorcovering in order to avoid matching of seams in underlay and floorcovering.

General building inspection NA

license:

Thickness: $2 \text{ mm} / \pm 0.2 \text{ mm} - \text{maximum tolerance } 10\%$

Dimensions: $15m \times 1m = \pm 15m^2$

Weight: $200 \text{ gr/m}^2 / \pm 20 \text{ gr/m}^2 - \text{maximum tolerance } 10\%$

Density: $100 \text{ kg/m}^3 / \pm 10 \text{ kg} - \text{maximum tolerance } 10\%$

Material: PE foam

Packing: None, with insert sheet.



Soundstop 2mm



Technical information:

Compressive strenght

(test method: EN 826 + Annex a)

: Class CSO - CS > 60kPa

Caster chair test

(Test method: EN 985)

: Passed

Impact sound reduction

(Test method: NA)

: $\Delta Lw = 19dB$

Thermal resistance

(Test method: NA)

: 0,45 togs - 0,045m² K/W

Fire retardency

(Test methode: EN ISO 9239-1)

: Efl

ASTM radial panel test

(Test methode: ASTM E 648-06)

: NA

Russian requirements on fire safety

(Test methode: FZ-123)

: NA

Installation instructions:

- · Let the floorcovering as well as the underpadding acclimatise for 24 hours in the original packing in the room to be installed.
- The best temperature for installation is 5-20°C. and a humidity of 50-70%.
- make sure that the underfloor is absolutely dry and free of grit and dust.
- To cut the underpadding we recommend to use a trapezium blade.
- Underpadding can not prevant the natural shrinkage of Floorcovering. For that reason we strongly advise to leave a gap a 8-10mm allong all walls. Always follow the installation instructions of the floorcovering manufacturer.

Important:

In case the installation has not been done in accordance with the installation instructions, estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.



